

- Find detailed instructions on how to use many TiVo features at bluestreamfiber.com/TiVo.
- Use the Help screens on your TiVo box. Go to Menu > Help > Tips & Troubleshooting.
- Visit Blue Stream Customer Service online at bluestreamfiber.com/TiVo or send us an email at info@bluestreamfiber.com.

© 2020 Xperi. All rights reserved. TiVo, the TiVo logo, OnePass, QuickMode, WishList, the Instant Replay logo, the Jump logo, the Thumbs Up logo and the Thumbs Down logo are registered trademarks of TiVo Brands LLC. Google, YouTube, Android TV and other marks are trademarks of Google LLC. iOS is a registered trademark of Apple Inc., registered in the U.S. and other countries. App Store is a service mark of Apple Inc. Hulu is a trademark of Hulu, LLC. Netflix is a registered trademark of Netflix, Inc. All other trademarks are the property of their respective owners.

For safety and compliance information, visit tivo.com/safety-compliance.



# TIVO EXPERIENCE

**Streaming Devices** 

## EVEN MORE YOU CAN DO...

## SPEAK AND YOU SHALL FIND

Press and release the Google Assistant button 😝 on your remote, and use your voice to find a show, open an app, or get recommendations to match your mood. Try saying things like "Bob's Burgers;" "Search cooking shows," or "Show me sports movies."

## ...OR SEARCH AND YOU SHALL FIND

Don't feel like talking? Use keyboard search to enter a title, actor name, or keyword instead. Your TiVo device instantly scans across all TV programming, On Demand, and streaming video apps to find exactly what you want.



## SKIP THE SURFING

To jump to one of your favorite channels while watching TV, press PAUSE to bring up the TrickPlay controls, then press DOWN to bring up your favorite channels.


Press DOWN a second time to view the Continue Watching panel.



## BE IN CONTROL WITH THE ALL-POWERFUL BLUE STREAM FIBER TV APP

Easily stream shows on your iOS or Android device using the TiVo app! (Bonus: The TiVo app also lets you schedule recordings, search for shows, and more, right from your mobile device!) Download the free TiVo app from the App Store.

- Watch live TV or recorded shows on your mobile device\*
- Schedule recordings from anywhere
- Browse current listings and What to Watch
- Manage OnePass selections and the To



## \* Requires compatible TiVo device and an iOS or Android device running current software.

## TO SEE OR NOT TO SEE

By default, the video you were watching when you entered the Home screen continues to play in the background. Similarly, on most other TiVo menu screens, a video window located in the upper right corner plays the current video as well.

To watch the video in full screen, press the BACK button on your remote control.

You can choose how to display a video on the Home screen, or choose to turn it off completely. Just select Menu > User Preferences > Video Window & Background.

- To turn video off on all screens, set Display Video to No.
- To continue to display video, set Display Video to Yes. You can then choose how to display it on the Home screen by modifying the Video on HOME settina:
  - Full screen (background): The currently-playing video is shown as a fullscreen video in the background of the Home screen
  - Video window (top right): The currently-playing video is shown in the upper-right corner of the Home screen.



**FULL SCREEN** 



TOP RIGHT



NO VIDEO ON HOME SCREEN

## THE TIVO REMOTE CONTROL

- 1 The TIVO BUTTON takes you to the Home screen.
- 2 POWER button turns the TV on or off.
- 3 INPUT selects the input for your TV.
- BACK goes back to the previous screen.
- Use the ARROW BUTTONS to navigate the TiVo menus. When watching video, press OK to bring up TrickPlay controls, UP to see the mini guide and DOWN to see the full Info banner, Continue Watching panel, and Favorite Channels panel.
- 6 VOLUME controls the volume on your TV.
- 7 Press and release the Google Assistant buttont to talk to Google.
- 8 REPLAY repeats the last eight seconds of the show. In the Guide, REPLAY jumps 24 hours back.
- 9 Use the THUMBS UP and THUMBS DOWN confirm certain commands, as instructed on screen.
- Future enhancements will include the use of the A, B, C, and D buttons. A opens the categories list in What to Watch. B changes the sort order of My Shows. C jumps to the next filter in My Shows. D removes a tile from the Continue Watching panel.
- 11 CLEAR dismisses items appearing over live TV and deletes titles from My Shows and the To Do List.



- 12 LIVE TV takes you to live TV.
- "i" shows the Info banner while watching a show. Press and hold for accessibility options.
- Use EXIT to go to full-screen video from any TiVo menu screen. While watching live TV or Start Over/Catch Up shows, EXIT goes back to the previous channel watched.
- Use CHANNEL UP/DOWN to change the channel or move quickly through the Guide.
- GUIDE takes you to the on-screen Guide.
- 17 Press RECORD to record the show you're watching, or to set up a recording for a show selected in the guide. (Cloud DVR required.)
- Use the TrickPlay buttons (REWIND, FAST-FORWARD, STOP, PAUSE, and PLAY) to control video.
- 19 ADVANCE jumps forward 30-seconds. In the Guide, ADVANCE jumps forward 24 hours.
- ON DEMAND jumps to the On Demand catalog.
- 21 The NETFLIX button launches the Netflix app.
- 22 ENTER/LAST displays the Continue Watching panel.

## WELCOME TO THE TIVO® EXPERIENCE!

The TiVo experience instantly gives you total control of the TV programming you love, and much more! Unlike traditional TVs and set top boxes that get a TV signal over a coaxial cable connected to a cable wall jack in your home, your TiVo streaming device gets the TV signal over a wired or wireless connection to your home network. You'll receive all of your channels, as well as access to streaming providers, over that one connection.

Want to record shows? Network/Cloud DVR allows you to record shows to watch later. The shows will be stored in the cloud for a specified period based on your OnePass settings.

## **HOME SCREEN**

## START HERE FOR JUST ABOUT EVERYTHING.

The Home screen is the starting point for just about everything you do with your TiVo box. From the Home screen, you can easily access popular destinations in the TiVo experience; get personalized recommendations from the SmartBar and What to Watch, and view settings.



To get to the Home screen from anywhere in the TiVo experience, just press the TiVo button on your remote control.

## MY SHOWS

### FIND. WATCH. REPEAT.

All of your recordings and streaming videos appear in the My Shows list. To get to the My Shows list from any menu screen or from live TV, just press the TiVo button twice. (Just select My Shows or press the TiVo button once if you're already on the Home screen.)



Filters in the left column of My Shows let you narrow your choices instantly. As you highlight a filter, your My Shows list will update automatically. Filters include TV Series, Movies, Kids, and more.

## **ONEPASS**

## YOUR TICKET TO LIMITLESS ENTERTAINMENT

OnePass gathers every episode of a series available anywhere and adds them all right to your My Shows list. If it's not available on TV or video on demand, OnePass fills in the gaps with episodes from providers like Netflix. To create a OnePass, find a show you want to watch, then choose "Create a OnePass."



## THE SMARTBAR

### READY WHEN YOU ARE

The SmartBar, located at the bottom of the Home screen, predicts shows to watch based on what your household usually watches at a particular time or day. For example, if the kids tend to watch shows while dinner's cooking, their shows will be waiting in the SmartBar at that time each day.



## MINI GUIDE

## **NEVER MISS A THING**

While you're watching video, press UP on your remote to reveal the mini guide. Use the mini guide to see what's upcoming on the selected channel, and to browse and switch to other channels



## WHAT TO WATCH

## **BROWSING 2.0**

So many channels, so little time! TiVo's What to Watch lets you browse shows available to stream, watch live, bookmark, or record. From the Home screen, select *What to Watch*.

